

TruWood™ Premium Timber

52"-60", TruWood Premium Timber Kit, Large

Part Number:
TWL-52/60-SP

INSTALLATION GUIDE

TruWood Premium Timber Kit models: OR52-MULTI,
OR54-TRAD, RS-5435, LPM-5616V2, OR60-MULTI.

TruWood Premium Timber Kit includes:

- 16" Large logs (3).
- 10" Slim log (1).
- 8" Slim logs (6).
- Bag of wood chips (1).

Assembly order

You will need to gain access to the ember bed of your fireplace. Refer to your fireplace manual for instructions for removing the front glass to access the ember bed.

Please Note: This kit is designed to fit multiple fireplace sizes. Your log set might be more spread out for linear fireplaces or more compact for traditional fireplaces. If your fireplace is one of the smaller units this kit is compatible with, you may not need to use all the logs based on the available space of your fireplace.

The placement is what we recommend and what we optimized the set to, but you can have fun with them and place them to your liking. We recommend placing the bark towards the flames for the best appearance and lighting contrast.

1. Ensure the ember bed media (crystals, fireglass, etc.) that came with the fireplace is installed first. If updating an existing fireplace, remove the old logs to accommodate the TruWood logs. Then select the 16" log from the kit and place it in the middle of the fireplace. This will be the base of the TruWood log layout.



2. Select the two 16" side logs and rest them on the left and right of the base log. These will create your main stack. Spread the logs out more for linear shaped fireplaces and bring them closer for traditional fireplaces.



Assembly order

3. Select two 8" logs, and stack these on the ends of the 16" logs.



4. Select two more of the 8" logs in your kit, and lay them under the 8" logs. The inside end of the log will be towards you and the outside end will be towards the flame screen.



Assembly order

5. This step may not be needed for 52" & 54" fireplaces. If you are happy with your layout continue to next step. For 56" and 60" select the last 8" logs, and lay these on top of the 8" logs previously stacked, crossing directions where possible.



6. Select the 10" center accent log and lay it across the main log diagonally.




Assembly order

7. Use the bag of wood chips and place a few chips and chunks in the gaps between the logs. We recommend using these sparingly for the best appearance and to maximize the light output from the ember bed.



52"-60", TruWood Premium Timber Kit, Large installation is complete.

Assembly order



Condensed layout example for Redstone and Orion Traditional Units

MODERN FLAMES®

ELECTRIC FIREPLACES

Thank you for choosing Modern Flames, we appreciate all our customers and hope you have many years of enjoyment of our products.

Take a look at our other products from our RPG Brands family of companies



GrandCanyonGasLogs.com

For all your indoor, outdoor gas fireplaces & fire feature products.



WildfireOutdoorLiving.com

For all your outdoor living products, such as grills, refrigerators and accessories.

RPG BRANDS

