

TruWood™ Premium Timber

68"-80", TruWood Premium Timber Kit, Large

Part Number:
TWL-68/80-SP

INSTALLATION GUIDE

TruWood Premium Timber Kit models: LPM-6816V2,
OR76-MULTI, LPM-8016V2.

TruWood Premium Timber Kit includes:

- 16" Large logs (3).
- 12" Large logs (2).
- 12" Slim logs (2).
- 10" Logs (2)
- 8" Accent logs (5).
- Bag of wood chips (1).

Assembly order

You will need to gain access to the ember bed of your fireplace. Refer to your fireplace manual for instructions for removing the front glass to access the ember bed.

Please Note: This kit is designed to fit multiple fireplace sizes. Your log set might be more spread out for linear fireplaces or more compact for traditional fireplaces. If your fireplace is one of the smaller units this kit is compatible with, you may not need to use all the logs based on the available space of your fireplace.

The placement is what we recommend and what we optimized the set to, but you can have fun with them and place them to your liking. We recommend placing the bark towards the flames for the best appearance and lighting contrast.

1. Ensure the ember bed media (crystals, fireglass, etc.) that came with the fireplace is installed first. If updating an existing fireplace, remove the old logs to accommodate the TruWood logs. Then select the 16" log from the kit and place it in the middle of the fireplace. This will be the base of the TruWood log layout.



2. Select the two 16" side logs and rest them on the left and right of the base log. These are now creating the main portion of your stack. Spreading these out more for linear shaped fireplaces and bringing these closer together for traditional shaped fireplaces.



Assembly order

3. Select the 12" large logs, and stack these on the ends of the 16" logs.



4. Select the 12" slim logs and lay them under the 12" large logs. The inside end of the log may be towards you and the outside end may be towards the flame screen.



Assembly order

5. Select the last two of the 8" Accent logs, and lay them under the 16" Side logs previously stacked, crossing directions where possible.



6. Select two of the 8" accent logs in your kit, and lay these over the 12" slim logs.



Assembly order

7. Select 8" center accent log and lay it across the main log diagonally.



8. Select the 10" logs in your kit, and stack these laying over the 12" Slim logs.



Assembly order

- Use the bag of wood chips and place a few chips and chunks in the gaps between the logs. We recommend using these sparingly for the best appearance and to maximize the light output from the ember bed.



68"-80", TruWood Premium Timber Kit, Large installation is complete.

MODERN FLAMES[®]

ELECTRIC FIREPLACES

Thank you for choosing Modern Flames, we appreciate all our customers and hope you have many years of enjoyment of our products.

Take a look at our other products from our RPG Brands family of companies



GrandCanyonGasLogs.com

For all your indoor, outdoor gas fireplaces & fire feature products.



WildfireOutdoorLiving.com

For all your outdoor living products, such as grills, refrigerators and accessories.

RPG BRANDS

